



How to reset password on Netscreen-10

created by: Rainer Bemsel - Version 1.0 - Dated: Julv/24/2005

Resetting the password on Netscreen-10 requires ScreenOS 2.61 and above. If your Netscreen runs 2.60, you will have to send the unit to Netscreen (or better said, Juniper). Netscreen is now part of Juniper. I've bought myself a Netscreen via eBay and figured out, that SceenOS 2.6.0r1.1 runs on the box, and of course, no password was available.

Luckily, the guy gave me a CD with newer ScreenOS.

If you don't have ScreenOS 2.61 available, I suggest you contact Juniper or a Netscreen certified Partner to help you in getting a newer ScreenOS.

Instead of using Default Login Name, you will have to use the Netscreen's own serial number for Login Name and Password.

Login: **14010338**

Password: **14010338**

```
!!! Lost Password Reset !!! You have initiated a command to reset the device to
factory defaults, clearing all current configuration and settings. Would you like to
continue? y/[n]: y
```

```
!! Reconfirm Lost Password Reset!! If you continue, the entire configuration of the
device will be erased. In addition, a permanent count will be incremented to signify
that this device ahs been reset. This is your last chance to cancel this command. If
you proceed, the device will return to factory default configuration, which is:
system IP: 192.168.1.1, username: netscreen, password; netscreen, Would you like to
continue?: y/[n]: y
```

In reset...

Finally, the Netscreen Box will restart..

```
NetScreen Technologies Inc.
NS10 System Monitor V2.1
Copyright, 1997-1999
```

```
32M SDRAM detected
SDRAM test0 passed
```

```
NetScreen Technologies, Inc
NS10 Load Software
Copyright, 1997-1999
Version 2.1
```

Hit any key for Boot/Diag mode

Hit any key for Boot/Diag mode



DISCLAIMER

This Technical Tip or TechNote is provided as information only. I cannot make any guarantee, either explicit or implied, as to its accuracy to specific system installations / configurations. Readers should consult each Vendor for further information or support.

Although I believe the information provided in this document to be accurate at the time of writing, I reserve the right to modify, update, retract or otherwise change the information contained within for any reason and without notice. This technote has been created after studying the material and / or practical evaluation by myself. All liability for use of the information presented here remains with the user.

Hit any key for Boot/Diag mode
Hit any key for Boot/Diag mode

Start loading...

.....
.....
.....
Done.

NetScreen Technologies, Inc
NS10 System Software
Copyright, 1997-2001

Load Manufacture Information ... Done
Load NVRAM Information ... (2.61)Done
Software version 2.6.1r13.1
Verify ACL register default value (at hw reset) ... Done Verify ACL register read/write
... Done Verify ACL rule read/write ... Done Verify ACL rule search ... Done
MD5("a") = 0cc175b9 c0f1b6a8 31c399e2 69772661
MD5("abc") = 90015098 3cd24fb0 d6963f7d 28e17f72 MD5("message digest") = f96b697d
7cb7938d 525a2f31 aaf161d0 Verify DES register read/write ... Done

Install modules (004e5140,00537b38) ... done(52) load dns table

This is a first-time system boot up.
Please use the "set clock" command to set system clock.

login: trust interface change state to Up System change state to Active(1)

login: **netscreen**
password: **netscreen**
ns10->
ns10->

That's pretty much all to do.

Now, you have a factory default reset Netscreen-10 Unit with default username and password.

